

Installation instructions:

- 1) Application area must be clean and dry . Remove any residue with a proper cleaner or degreaser. Clean surface with 70% Isopropyl Alcohol.
- 2) Cut molding to proper length using anvil type cutter.
- 3) Pull off 6 inches of red liner and begin to apply molding. With one end of molding adhered to surface, pull red liner away from molding as you apply the remaining length.
- 4) Use a roller to apply pressure along the entire length of the applied molding. Do this several times, you cannot use too much pressure. The palm of your hand can also be used when a roller is not available.
Note: A. Apply molding in the proper position on the initial application. This adhesive has a very high bond and should not be repositioned.
B. Very Important: After pulling off red liner, do not touch the gray adhesive with your fingers...hold molding by its sides.
- 5) Use Damp Cloth for cleaning CHROME molding. Do Not use abrasive compounds.
- 6) Allow molding 24 hours to set.

We use only 3M *ACRYLIC FOAM TAPE* on our products.

Warranty

Warranty is limited to the replacement of Precision Trim Molding returned prepaid to the manufacturing location and found to be defective. This warranty is void if the product is not used prior to twenty-four (24) months from date of manufacture. These products are intended for automotive use only. No liability can be assumed for any other use.